

**BH002
PLASTIC PANEL**



**BH032
HITCH PIN**



**BZ007
REMOTE HOLDER**



**BZ009
CLEVIS**



**BZ015
FLAT MOUNT PULLEY**



**BH035
WINCH**



**BZ020
EYE BOLT**



**BZ032
STEERING ARM**



**BZ038
BRASS BUSHING**



**BZ047
LYNCH PIN**



**BZ046
STEERING SPRING**



**BZ058
BATTERY BRACKET**



**BZ059
BATTERY BOLT**



**EB133
HANDLE GRIPS**



**BZ024
BASE**



**BZ055
LOWER JACK BRACKET**



**BZ062
UPPER JACK BRACKET**



**BZ016
PULLEY BRACKET**



**BZ037
PLASTIC WASHER**




**BZ040
SHIM**




**BZ039
SPACER BUSHING**



**BZ067
JACK**



**BZ066
SHIELD**



**BH012
EXTENTION POST**



BZ026
CASTER FORK LONG



BZ027
CASTER FORK SORT
(Specify right or left)



BH024
CIRCUIT BREAKER



BZ052
CHARGER RECEPTICAL



BZ050
HANDLE LOWER



BZ049
HANDLE UPPER



BZ042
WHEEL



BZ075
WHEEL BEARING



**BZ021
SPINE SHAFT**



**BZ028
TIE ROD**



**BZ030A
43in BASE CHAIN**



**BZ030B
48in UPPER CHAIN**



**BZ001
SPINE**

